




## Operations Manual

### BJT-520B

### 12 Volt & 24 Volt Ground Power Units

# T-REX



SYDNEY AUSTRALIA  
DESIGNED & MADE



Durst Industries (Aust.) Pty Ltd.  
1/11 Packard Ave. Castle Hill  
NSW 2154 Australia

 [DURST.COM.AU](http://DURST.COM.AU)  
 [SALES@DURST.COM.AU](mailto:SALES@DURST.COM.AU)  
 INTL +61 2 9660 1755



## INTRODUCTION

The T-Rex BJT-520B is a high-capacity mobile jump starter designed for 12V or 24V systems. It is suitable for a wide range of applications—cars, trucks, buses, defense vehicles, mining, and aviation. The heavy-duty steel enclosure, large pneumatic wheels, and integrated safety features make it ideal for demanding industrial and commercial environments.

BJT-520B-A — Anderson Output Port

BJT-520B-C — CAT Output Port

BJT-520B-N — NATO Output Port

## 1. PART NUMBERS

### **BJT-520B-A Slave Lead Options:**

- LS-3AI-95 (3m, 95mm<sup>2</sup>, Anderson to Clamp)
- LS-6AI-95 (6m, 95mm<sup>2</sup>, Anderson to Clamp)

### **BJT-520B-C Slave Lead Options:**

- LS-3CC-70 (3m, 70mm<sup>2</sup>, CAT to CAT)
- LS-6CC-70 (6m, 70mm<sup>2</sup>, CAT to CAT)

### **BJT-520B-N Slave Lead Options:**

- LS-3NN-95 (3m, 95mm<sup>2</sup>, NATO to NATO)
- LS-6NN-95 (6m, 95mm<sup>2</sup>, NATO to NATO)

Choose the Slave Lead configuration that matches your vehicle or aircraft's connector type. Always confirm the correct Slave Lead before connecting to ensure compatibility and a safe start procedure.

**512-86 130 Ah Battery**

**BJF-500-TREX Fuse pack**





## 2. SAFETY WARNINGS

- **NO SMOKING OR OPEN FLAMES:** Batteries can emit explosive gases; operate in a well-ventilated area away from sparks or flames.
- **AUTHORIZED PERSONNEL ONLY:** Ensure operators have training or prior experience with high-current jump starters or GPUs.
- **CORRECT VOLTAGE:** The T-Rex BJT-520B can supply 12V or 24V. Check your vehicle or aircraft manual for the correct voltage setting.
- **OEM GUIDELINES:** Always follow the manufacturer's recommended procedure for external jump-start connections on ground vehicles or aircraft.

## 3. KEY FEATURES & SPECIFICATIONS

- **VOLTAGE OUTPUT:** 12/24V (selectable via main switch)
- **CRANKING AMPS (CA):** 5,400 (12V) / 2,700 (24V)
- **COLD CRANKING AMPS (CCA):** 4,800 (12V) / 2,400 (24V)
- **PEAK AMPS (EST.):** ~24,000 (12V) / 12,000 (24V)
- **ENCLOSURE:** Powder-Coated Steel with Large Pneumatic Wheels
- **WEIGHT:** ~257 kg (use mechanical assistance for moving)
- **DIMENSIONS:** L 1170 mm × W 720 mm × H 670 mm
- **CHARGER:** Automatic Built-in SwitchMode BCS-2425C (24V, 25A)

Each unit includes built-in Reverse Polarity Protection, Anti-Spike Protection, and Fuse Protection for safe operation.



## **4. OPERATING INSTRUCTIONS**

### **4.1 PRE-CONNECTION CHECKS**

1. Confirm the Unit is OFF
  - › The main isolation switch must be set to OFF before handling connections.
2. Check Emergency Switch Indicator (if equipped)
  - › Ensure that any emergency or safety switch is in the OFF/SAFE position before attaching cables or leads.
3. Select Correct Slave Lead
  - › Depending on your T-Rex BJT-520B version (A, C, or N), attach the corresponding Slave Lead (e.g., Anderson to Clamp, CAT to CAT, or NATO to NATO).

### **4.2 CONNECTING TO VEHICLE OR AIRCRAFT**

1. Attach Slave Lead
  - › Connect the lead from the OUTPUT CONNECTOR on the T-Rex GPU to the matching SLAVE CONNECTOR on the vehicle or aircraft.
  - › OR, if using clamps (BJT-520B-A with Anderson-to-Clamp leads):
    - › BLACK (-) clamp to negative terminal or unpainted vehicle ground.
    - › RED (+) clamp to positive battery terminal.
2. Check for Alarms
  - › If a buzzer sounds or a warning light shows Reverse Polarity, STOP immediately and verify connections.
3. Observe Voltmeter
  - › With the T-Rex switch still OFF, the voltmeter displays the battery's standing voltage.



### 4.3 ACTIVATING THE T-REX GPU

#### 1. Select Voltage

- › Turn the MAIN SWITCH to 12V or 24V according to the vehicle/aircraft requirements.

#### 2. Confirm Output

- › The voltmeter changes to the T-Rex GPU output voltage.
- › A green indicator typically confirms the active voltage level.

### 4.4 MONITORING & USAGE

#### › Continuous Monitoring

- › Watch the voltmeter to confirm stable voltage.
- › If the battery or T-Rex GPU shows irregular readings, switch OFF and inspect.

#### › Load / Engine Start

- › Start the vehicle or aircraft as per normal procedures.
- › Once running, switch the T-Rex GPU back to OFF before removing leads.

### 4.5 DISCONNECTION PROCESS

#### 1. Switch OFF

- › Turn the main switch to OFF.

#### 2. Remove Leads

- › Disconnect the slave connector or clamp leads from the vehicle or aircraft.
- › Store them securely on the T-Rex GPU to prevent damage.





## **5.1 CHARGING THE T-REX BJT-520B**

### **1. Switch OFF**

- Always place the main switch in the OFF position prior to charging.

### **2. Connect AC Power**

- Plug the AC power lead into the IEC socket labeled "AC IN."
- A red charge indicator lights when connected to mains.

### **3. Battery Optimization Display (if equipped)**

- Monitors charging voltage, current, and temperature in real time.
- Shows faults or error codes if charging is interrupted.

### **4. Keep Charged**

- Maintain the T-Rex GPU on AC power whenever possible to keep batteries at full capacity.



## **5.2 MAINTENANCE**

### **1. Battery Care**

- Check charge levels and top up as needed.
- Operating the T-Rex GPU at low battery voltage can reduce performance.

### **2. Lead/Clamp Inspection**

- Inspect the leads for frayed insulation, loose connectors, or corrosion.
- Clean any corrosion using a mild solution (e.g., baking soda) and a wire brush.

### **3. Fuse Replacement**

- Use only fuses approved by Durst (Part No. BJF-500-TREX, if relevant).
- If unsure about fuse specifications, contact an authorized Durst service center.

### **4. Exterior Cleaning**

- Wipe down the unit with a soft cloth. Avoid high-pressure water jets or harsh chemical cleaners.

## **5.3 STORAGE GUIDELINES**

- Environment
  - Store indoors, in a dry, clean area.
- Switch Position
  - Keep the main switch OFF when not in use.
- Long-Term Charging
  - If possible, leave connected to AC power for battery maintenance.





## TROUBLESHOOTING

ISSUE	POSSIBLE CAUSE	SUGGESTED ACTION
Buzzer or Warning Light	Reverse polarity / incorrect lead connection	Disconnect and re-check clamp or connector.
Low or No Output Power	T-Rex GPU battery undercharged / fuse blown	Recharge fully; replace fuse if necessary.
Vehicle Won't Start	Insufficient capacity or large load draw	Confirm vehicle battery health; fully charge T-Rex GPU.
Overheating	Extended high-load operation / poor ventilation	Switch OFF, allow unit to cool; ensure vents are clear.
Voltmeter Inactive	Main switch OFF, or cables disconnected	Check switch/cable connections; re-test.



## SPECIFICATIONS AT A GLANCE

T-REX+ BJT-520B	
Voltage	12/24 V
Cranking Amps	5,400 (12 V) / 2,700 (24 V)
Cold Cranking	4,800 (12 V) / 2,400 (24 V)
Peak Amps	~24,000 (12 V) / 12,000 (24 V)
Weight	~257 kg
Cable Set	Primary: 3.0 m, 95 mm <sup>2</sup> ; plus Secondary leads for split bank
Charger	Automatic BCS-2425C (24 V / 25 A)
Dimensions	L: 1170 mm x W: 720 mm x H: 670 mm

## DISCLAIMER & SUPPORT

**Intended Use:** The T-Rex BJT-520B jump starter is engineered for professional applications requiring high cranking current at 12V or 24V. Consult the vehicle/aircraft manufacturer for instructions on external GPU usage.

**Liability:** Durst Industries (Aust.) Pty Ltd. is not liable for damage due to misuse, unauthorized modifications, or improper handling.

**Contact:** For parts, servicing, or technical support, visit [durst.com.au](http://durst.com.au) or call +61 2 9660 1755.



Durst Industries (Aust.) Pty Ltd.  
1/11 Packard Ave. Castle Hill  
NSW 2154 Australia

 **DURST.COM.AU**  
 **SALES@DURST.COM.AU**  
 **INTL +61 2 9660 1755**